



INSTALLATION INSTRUCTIONS

1. Remove swivel feet from telescopic legs
2. Remove the telescopic legs from the Black Adda unit
3. Remove the lock nuts from the threaded rods supplied
4. Insert threaded rods through one side of the Black Adda
5. Then insert the 1st half of the Black Adda (with the rods) through the bottom two rungs of your ladder Note: Pin housing to face climbing side of ladder
6. Mark the rod 20mm from the outside edge of ladder rung (be sure that the rods are fully home into the Black Adda unit)
7. Remove and cut the marked threaded rod
8. Repeat steps 4 & 5
9. Position the 2nd half of the Black Adda over the rods and flush to rungs
10. Using spanners supplied firmly tighten the Black Adda to your ladder with the nylock nuts (recommended torque 12nm 8.5 foot pound)
11. Insert the telescopic legs, attach the swivel feet then tighten to allow for foot movement

